

Visualizer Projection

General

Instructions are given with assumption that operator is facing the visualizer unit

- Plug cart cord (black) into power outlet
- Turn power button on left side **ON** if it is in the **OFF** position
- To turn illuminator on, press and release **UPPER** button under the **LAMP** heading on the left front edge of visualizer
- Attach visualizer to projection equipment per instructions for the specific system.
- **Gently** lay item to be displayed on the white illuminator panel
- FOCUS VISUALIZER by:
 - Press and hold the **TELE** button until lens is “zoomed” in to item on panel
 - Press and release the **AUTO FOCUS** button
 - Press the **WIDE** button to display item at the desired size
 - Item displayed may be magnified by pressing the **TELE** button under the **ZOOM** heading on the front edge of the visualizer
 - Pressing the **WIDE** button under the **ZOOM** heading will move the lens away from the displayed item, showing more of it on the screen
- **Be sure to “shut down” all equipment correctly.**

Use as a CAMERA

- Connect to the projection system per instructions for the specific system.
- Point the lens on the upper visualizer arm toward the object to be projected on the screen.
- Adjust focus as necessary

6/2/2005 9:16 AM
visualizerprojection.doc